



| Pos. | Artikelbeschreibung | Description of item | Artikel Nr./Item No. |
|-------|-------------------------------|-----------------------------------|----------------------|
| 3 | Auflagerost | Grid support shelf | E070201107419L |
| 4 | Griff | Handle | E070200700664 |
| 5 | Gitterrost | Grid | E070201107428L |
| 7 | Relais | Relay | E070100900791 |
| 8 | Timer | Digital timer | E070101001837L |
| 9 | Kontrolllampe, gelb 250V, 14A | Indicator light, yellow 250V, 14A | E0301130005 |
| 10 | Thermostat 50-300°C | Thermostat 50-300°C | A039884 |
| 11+12 | Knebel z. Thermostat | Thermostat knob | E0301110009 |
| 13 | Heizungsanzeige | Heating indicator | E070101300119 |
| 14 | Energieregler | Energy regulator | E070100800400 |
| 15 | Marquardt Schalter, 20 A grün | Marquardt switch, 20 A green | 016210836 |
| 16 | Klemmleiste | Terminal block | E070100701800 |
| 17 | Temperaturfühler | Temperature sensor | E0301030198L |
| 18 | Fuß | Foot | E070200900219 |
| 20 | Zugentlastung | Power cord sheath | E070100700728 |
| 21 | Anschlusskabel | Power cord | E070100500273 |
| 24 | Heizelement oben | Heating element top | E070100410655L |
| 27 | Heizelement unten | Heating element bottom | E070100410646L |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |



Griddle-Salamander 6640
Artikel-Nr.: 100533

Ersatzteilliste
11.01.2023