



Serial number - XXX - - - - - or XXX - - - - -

N° de série - XXX - - - - - ou XXX - - - - -

Where XXX set for:

Où XXX vaut :

| |
|----------------------------|
| R8 096 |
| R10D 116 117 118 |
| R20D 119 120 121 |

| |
|----------------------------|
| R8E 512 513 593 |
| R10E 514 515 594 |
| R15E 516 517 595 |
| R20E 518 519 596 |

| |
|----------------------------|
| R23A 610 626 |
| R30A 611 627 623 |
| R45A 612 628 624 |
| R60A 613 629 |

